








BERLIN


Active Grip Set Handle K-C2080







What's in the box				
Pos	Qty	Description		
1	1	Interior plate		
2	1	Exterior handle set with cylinder, actuator and gasket		
3	1	Interior handle with set screw		
4	1	Set of three keys		
(5)	2	M5 x 65mm installation screws for 1 3/4" doors		
6	1	Allen key 2,5mm x 100mm		




BERKELEY


Active Grip Set Handle K-C2070








What's in the box				
Pos	Qty	Description		
1	1	Interior plate with knob		
2	1	Exterior handle set with cylinder, actuator and gasket		
3	1	Interior handle with set screw		
4	1	Set of two keys		
(5)	2	M5 x 65mm installation screws for 1 3/4" doors		
	2	M5 x 75mm installation screws for 2 1/4" doors		
6	1	M5 x 45mm bottom screw for 1 3/4" doors		
	1	M5 x 60mm bottom screw for 2 1/4" doors		
7	1	Bottom screw washer		
8	1	Bottom screw cover with set screw		
9	1	Handle nylon washer		
10	1	Allen key 2,5mm x 100mm		



Door Thicknesses












SOLD SEPARATELY

ACTUATOR KIT K-C2054-57-0-0






SOLD SEPARATELY

ACTUATOR KIT K-C2054-70-0-0






SOLD SEPARATELY


ACTUATOR KIT K-C2054-76-0-0

Door Openings


















OUTSIDE


Left Handed Doors (LH)













Left Handed Doors (LH)

Reverse the actuator on the exterior plate











Install the Handle

On the interior plate










Install the Handle

On the interior plate










Install the Exterior Assembly On the door panel










Install the Interior AssemblyOn the door panel










Install the Interior AssemblyOn the door panel










Install the Interior AssemblyOn the door panel










Install the Bottom Screw Cover On the door panel (for BERKELEY only)











Check the Operation





STEP 13 KEEP DOOR OPEN WHEN TESTING THE OPERATION





Care and Maintenance





For use in a coastal or humid environments, during installation, add lithium grease on fixation screw to prevent galvanic corrosion over time



HANDLE TRIM

To prevent build-up of surface contaminates, possibly resulting in hardware surface deterioration; we recommend to wipe down with soft cloth all visible surfaces with warm water and mild soap. Then wipe the same surfaces with a clean cloth and warm water only and let surfaces dry completely.

For all finishes, it is strongly recommended to apply a non-abrasive automotive wax to protect the surface.

This procedure should be done a minimum of 2 times per year.

MULTIPOINT DOOR LOCKS

In order to ensure the smooth operation of the lock over a long period of time, it is necessary to lubricate all movable parts and locking points using acid and resin free lubricants.

The use of caustic cleansers or chemicals should be avoided.



Convert Active to Dummy


For inactive doors








FOLLOW THE CONVERSION INSTRUCTIONS INCLUDED WITH THE KIT







FERCO	



FERCO	

HEAD OFFICE

Ferco Architectural Hardware Inc. 2000 Rue Berlier Laval, QC H7L 4S4 Canada

T 450 973-1437 1800355-8810 F 450 973-7661 ferco@ferco.ca

ONTARIO

T 905 282-9588 F 905 282-9915 UNITED STATES

T 1 800 927-1097 F 1 888 454-0161

www.ferco.ca





