



## Astragal Mortise Lock for Inactive Doors

### Faceplate Finishes





Dark Bronze PC



Black PC



# SIMPLY FLIP THE LEVER!

### It will secure the top and the bottom of the inactive door

#### The Advantages

- None handed, easy to reach and operate
- Lever will give more leverage locking the shoot bolt into the striker cup
- 20mm stainless steel faceplate can be installed after finishing the door
- Adjustable backset (rod depth) 24-33 mm. Accommodate different astragal thickness from 1/2" to 11/8"
- Two set screws capture each rod securely in place, no threaded rods are required
- 10mm rods extend 25mm (1")
- Straight rod cut off from the hookup side, no grinding tip or retreading required
- Fixed rod sizes available for standard doors
- For doors up to 11' height
- Set screws (with locktite) to fasten the rods are concealed behind faceplate
- Nylon guide for top and bottom rods
- 304 stainless steel top and bottom reinforcement plates to support the rods
- Easily accessible rod height adjustment
- Jig and router bit available
- Adjustable top and bottom striker cups: in and out 1mm, sideways 6mm.
   Two height sizes 22 and 27mm

Colors on this document are graphic representation and may not be an exact match for the actual painted/plated hardware. For color selection, material samples are available on request.

QUÉBEC / MARITIMES Ferco Ferrures de Bâtiment Inc.

2000, Rue Berlier Laval, QC H7L 4S4 Tel.: 450 973-1437 1 800 355-8810

1 800 355-8810 Fax: 450 973-7661 ferco@ferco.ca www.ferco.ca ONTARIO / WESTERN PROVINCES
Ferco Architectural Hardware Inc.

Tel.: 905 282-9588 1 800 668-5310 Fax: 905 282-9915 **UNITED STATES** 

Ferco Architectural Hardware Inc.

Tel.: 1 800 927-1097 Fax: 1 888 454-0161



